





- 1** Apply Energy Saver double sided tape along the edge of the framed opening. Remove paper from tape.
- 2** Apply the Energy Saver fabric over the opening. Cut the fabric as indicated leaving pieces to wrap framed opening.
- 3** Tape the Energy Saver fabric using double sided tape to the inside of the frame opening.
- 4** Caulk all corners and openings to ensure an airtight seal.

SIL810-001 4/17

Drawing not to scale



## Energy Saver Framed Wall Opening