





- 1 Apply Energy Saver double sided tape along the edge of the framed opening. Remove paper from tape.
- 2 Apply the Energy Saver fabric over the opening. Cut the fabric as indicated leaving pieces to wrap framed opening.
- 3 Tape the Energy Saver fabric using double sided tape to the inside of the frame opening.
- 4 Caulk all corners and openings to ensure an airtight seal.

SIL810-002 8/19

Drawing not to scale